

## Frequently Asked Questions

### PowerSourcePro 1000w Inverter (RINV1000)

Q. There is an alarm sounding from my inverter?

A. 1) The inverter alarm will sound if the input voltage drops to 10.5 volts. This indicates the battery will need recharging.

Q. My inverter has shut down automatically?

A. 1) All power source inverters are internally fused. All cigarette adaptors are also fused. Check fuses.

2) If the input voltage exceeds 15v then the inverter will automatically shut down.

3) If the input voltage drops below 10v the inverter will shut down leaving enough battery voltage to restart the vehicle.

4) If the appliance has a wattage higher than the inverter specification then it will shut down automatically.

Q. The inverter has cut out after continuous use?

A. The thermal cut out has shut down the inverter as it has exceeded 65°C. Switch off, leave to cool and it will automatically reset.

Q. Can all 1000w be drawn through 1 socket?

A. Yes all 1000w can be drawn through 1 socket.

Q. Why are there 2 sets of cables with the inverter?

A. The second set of cables are connectd if a secondary battery is used to power the inverter. If only 1 battery is present only 1 set of cables are required.

Q. When do the internal fans come on?

A. The fan / fans are thermally controled and will activate when the inverter reaches a preset temperature.